

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match.
The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.
Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A.*

C-A OPERATIONS PROCEDURES MANUAL

7.1.19 Adsorber Bed A Online and Adsorber Bed B Offline

Text Pages 2 through 4

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: _____ *Signature on File* _____
Collider-Accelerator Department Chairman Date

D. Lederle

7.1.19 Adsorber Bed A Online and Adsorber Bed B Offline

1. Purpose

This procedure provides instructions for placing adsorber bed A online and taking adsorber bed B offline. This procedure will be performed when adsorber bed B is contaminated and being taken offline for regeneration. The steps necessary to regenerate adsorber bed B are not covered under this procedure, please reference [C-A OPM 7.1.22](#).

2. Responsibilities

- 2.1 The Shift Supervisor, or an Operator designated by the Shift Supervisor, is responsible for conducting the procedure and providing documentation in the Cryogenic Control Room Log.
- 2.2 Should a problem arise in the process of regenerating the adsorber bed, the Shift Supervisor shall report to the Technical Supervisor for instructions before continuing.

3. Prerequisites

- 3.1 Operator shall be familiar with the refrigerator P&ID drawing 3A995009, the physical location of components on the refrigerator, and the refrigerator control pages found on the CRISP control system.
- 3.2 Adsorber Bed "A" has been regenerated per [C-A-OPM 7.1.21, "Regeneration of Adsorber Bed "A" "](#). Adsorber Bed "A" is clean and ready for service if inlet valve H362A is open and outlet valve H371A is closed.
- 3.3 The oxygen monitor and hygrometer in the compressor room shall be set to read the compressor discharge.

4. Precautions

- 4.1 If there is liquid helium in the refrigerator pots, all personnel entering the refrigeration wing of 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM), and carry an emergency escape pack.

5. Procedure

- _____ 5.1 Date _____
- _____ 5.2 Ensure closed valves H9090M_____, H898M_____, and V263M_____.
- _____ 5.3 Open valves H9089M_____ and H899M_____.
- _____ 5.4 Crack open valve H897M.
- _____ 5.5 Monitor TI369H, adjust valve H897M, as needed, to achieve a temperature drop of approximately 15°K/10 minutes.
- _____ 5.6 Open valve H371A when TI369H is within 10°K of TI769H and below 100°K.
- _____ 5.7 Should any sustained increase in the O2 or H2O monitors at compressor discharge appear, stop this procedure and regenerate adsorber "A" as per [C-A-OPM 7.1.21](#).
- _____ 5.8 Close valves H897M_____, and H899M_____.
- _____ 5.9 Close valve H771A when TI369H and TI769H are equal and stable.
- _____ 5.10 Close valve H762A.
- _____ 5.11 Enable logic alarm on adsorber bed "A".
- _____ 5.12 Open valve H9092M.
- _____ 5.13 Crack open valve H9093M to vent "B" adsorber.
- _____ 5.14 When adsorber "B" is at approximately 10 atm, close valves H9093M_____.

- _____ 5.15 When thawed, close valves H9089M_____ and H9092M_____.
- _____ 5.16 If adsorber bed "B" was taken off line due to contamination, start regeneration process as specified in [C-A OPM 7.1.22](#).

6. Documentation

- 6.1 The check-off lines on the procedure are for place-keeping only. The procedure is not to be initialed or signed, it is not a record.
- 6.2 The Shift Supervisor, or designee, shall document the completion of the procedure in the Cryogenics Control Room Log.

7. References

- 7.1 Drawing 3A995009, 25kW Helium Refrigerator P&ID.
- 7.2 [C-A-OPM 7.1.22](#), "Regeneration of Adsorber Bed "B".
- 7.3 [C-A-OPM 7.1.21](#), "Regeneration of Adsorber Bed "A".

8. Attachments

None